

---

INSTRUCTION MANUAL

---

**LW 450 D**  
**DIESEL**

■

**BREATHING AIR**  
**COMPRESSOR**



**LENHARDT & WAGNER GmbH**  
**An der Tuchbleiche 39**  
**D-68623 Lampertheim - Hüttenfeld / Germany**

Phone.: +49 62 56 – 85 880 0  
 Fax: +49 62 56 – 85 880 14  
 www.lw-compressors.com  
 Mail: info@lw-compressors.com

Technical Data	LW 450 D
Delivery Capacity:	450 l/min
Max. Pressure:	350 bar
RPM Compressor:	1,100 min <sup>-1</sup>
No of Pressure Stages:	3
Cylinder Bore 1st Stage::	Ø 95 mm
Cylinder Bore 2nd Stage:	Ø 42 mm
Cylinder Bore 3rd Stage:	Ø 18 mm
Medium:	Air
Intake Pressure:	atmospheric
Oil Pressure:	+2.0 bar
Oil Capacity:	2.2 ltr
Intake Temperature:	0 < +45°C
Ambient Temperature:	+5 < +45°C
Cooling Air Requirement:	> 3,300 m <sup>3</sup> /h
Drive Motor	Hatz Diesel 1 D 81 C
Protection Class Drive Motor	IP 54
Motor Power / Capacity:	10.5 kW / 667cc
RPM Motor:	3,600 min <sup>-1</sup>
Engine oil capacity:	1.9 litre <i>incl. oil filter</i>
Dimensions:	length: 1,280 mm height: 100 mm width: 740 mm weight: 430 kg
Capacity Filter Housing:	1.7 ltr.

## S A F E T Y P R E C A U T I O N S

### General Notice

This instruction manual contains the operation and maintenance procedures necessary to safely run your L&W compressor.

We strongly recommend to read this manual thoroughly prior operation and to follow all the safety precautions precisely.

Damage resulting from any deviation from these instructions is excluded from warranty and liability for this product.

Be sure to pay attention to the following points:

- Fill only tanks with a valid hydrostatic test date
- Never exceed the working-pressure rating indicated on the tank
- Carry out proper maintenance on the compressor and filtration system
- Care must be taken to avoid the intake of contaminated air in to the compressor
- Do not exceed maximum operating temperatures

### Safety Precautions

- Read the operation manual of your compressor carefully
- Allow only qualified personnel to run the compressor
- Do not place any objects on compressor while in operation
- Make sure no person or object can accidentally touch any moving parts while running
- Take care that the intake-air is pure and free of toxic gases
- All work on compressor must be carried out while compressor is disconnected for the power supply and depressurized
- Check unit regularly for air- & oil leaks
- Never weld damaged high-pressure tubes
- Filling-hoses must be in perfect condition; special attention should be paid to the connecting fittings
- Do not touch any hot compressor / engine parts while doing maintenance work as these may cause injury by burning. Wait until unit has cooled down.

---

## Method of Operation

Air comes through a micro filter into the first stage, is compressed and leaves through the heat exchanger into a water /oil separator.

A short pipe leads the air into the second cylinder and is further compressed, leaving again through a heat exchanger and the second water /oil separator and then compressed in the third stage to the final pressure.

The air then goes through the after cooler and into the mole carbon filter.

The purified air goes through a safety valve and into the pressure maintaining valve, there to the air manifold and filling hoses or, if required, into an external filling panel.

---

## Drive Engine

The drive engine is a sound isolated 10.5 kW Hatz Diesel (Type: 1D81C) It is mounted on special rubber engine mountings to a 2-piece base plate.

For maintenance and operation please also refer to the original Hatz instruction manual



**Hatz Diesel Engine Type 1D81C & Battery**

---

## V-Belt Tension

A correctly adjusted V-belt does just not slip when starting the compressor.

To adjust the V-belt tension loose the four mounting screws and adjust the V-belt by means of the tension screw.

Over tightening of the V-belt can cause damage to the electric motor and compressor bearings.

---

---

## Installation

Don't place compressor closer than 0.5 m to any wall and ensure good ventilation.

**NOTE: Pure air intake is very important!**

---

## Filling process

Fill only air tanks which are:

- suitable for final pressure.
- hydro static tested (check last testing date).

The automatic switch off, or safety valve, has to be checked before tanks can be filled:

- Close filling valves.
  - Start compressor by ignition key and drive to maximum pressure. The compressor should automatically switch back to idle speed, to prevent overcharging (if failing to do so, the faulty parts have to be replaced before proceeding).
  - Connect tanks to compressor. Filling valve and tank are still closed.
  - First slowly open filling valve.
  - Carefully open tank valve.
  - Engine will switch back to max. revs if pressure falls below 280 bar.
  - The compressor will automatically return to idle speed, once the tanks are filled with max. pressure.
  - First close tank valve.
  - Close filling valve.
  - Release pressure between tank and filling valve by rotating the vent screw (hissing sound can be heard).
  - Disconnect tank from compressor.
  - Turn off compressor by ignition key.
- 

## Automatic Condensation Dump System

The L&W 450 D Diesel compressor comes as standard with an auto dump system. Solenoids are open (and drain all water separators) when the compressors runs at idle speed. If the filling process takes longer than 20 minutes the blue button on the dash panel has to be pushed for about 5 seconds.

---

## Intake Filter

A micro filter cartridge is used as an air intake filter. We recommend that the filter cartridge should be replaced after 60 to 100 working hours.

A dirty, contaminated filter restricts the airflow, reduces the compressor's capacity and causes overheating.

---

---

## Cylinder Heads and Valves

Inlet and outlet valves are located in the cylinder heads. The inlet valve opens on the down stroke. The outlet valve opens on the upstroke. The valves should be replaced after 1,000 working hours due to normal wear and tear. To replace the valves the cylinder heads have to be removed. All three valves are combined valves. Inlet and outlet valves form one unit. The first and second stage valves are plate valves. The third stage valve uses a spring operated piston in a brass cylinder. This valve sits loose with an O-ring seal in the cylinder head. To change valves no special tools are required.

---

## Safety Valves

Every compression stage features a separate safety valve to protect the compressor unit from overpressure.

LW 450 D/E/ES safety valves are adjusted to the following relief pressures:

**1<sup>st</sup> Stage: 8 bar**

**2<sup>nd</sup> Stage: 50 bar**

**3<sup>rd</sup> Stage: final pressure**

If a safety valve starts leaking, this indicates problems with either inlet or outlet valve of the next following compression stage.

**NOTE: Faulty safety valves should always be replaced!**

---

## Lubrication

The crankshaft is lubricated by an oil slinger.

1st and 2nd Stages are lubricated by spray oil.

The 3rd Stage is lubricated by a mechanical oil pump.

2.2 litre of synthetic oil (order no. L&W 000001) is required for an oil change.

**NOTE:** The oil level never should be lower than the red marking on the oil level indicator glass (located on the left hand side of the compressor crankcase).



**Oil Pressure Switch & Oil Pump**

---


## Starting the compressor for the first time

- Place the compressor in a distance of at least 50 cm to any walls (Ambient temperature max. +45°C).
- Make sure your location is properly vented due to exhaust gases
- Check oil level on Hatz engine.
- Check fuel level
- Check battery fluid level and connections
- Check oil level on compressor.
- Check if air filter cartridge is in place.
- Make sure all filling valves are closed.
- Position speed switch to **0** (idle speed).
- Start engine by ignition key.
- Turn speed switch to **1** (full speed) after about 5 seconds (depending on air temperature).
- Watch oil pressure warning lamp.
- Run compressor to max. pressure.
- Check if safety valve opens at max. pressure.
- Check compressor unit for air leaks.
- Check auto dump valves for function by pushing the blue switch on the dash panel.
- Turn off compressor by start switch.
- Release pressure by filling valves.

## Oil / water separator

There are oil / water separators (condensation separators) fitted after every compression stage. These were automatically drained every 15 minutes by solenoid valves (auto dumps). L&W condensation separators are maintenance free. However, we do recommend, to have them cleaned every 200 working hours.

Also check condition of the O-rings and replace them if necessary.




**1st & 2nd Stage Water Separators**

## Auto Drain System

Condensate will be separated after every stage of compression. All three separators are fitted with solenoid valves which are controlled by an electric timer.

The timer is located in the electro box and activates the dump valves every 15 minutes to release the condensate through plastic hoses.



**Final Stage Water Separator with Silencer**

We recommend to use of a 20 litre container to collect the liquid condensate.

It can then be disposed of like discarded oil.

The drain noise is kept to a minimum with a silencer.


## Operation Panel

- 1) Start switch
- 2) Battery load indication lamp
- 3) Oil pressure gauge for diesel engine
- 4) Temperature control lamp (diesel engine)
- 5) Condensate drain test-button
- 6) Selector switch (idle / load)



**Operating panel LW 450 D**


- 7) Pressure gauge
- 8) Hours counter



## Safety Switch (Cover Lid)

**LW 450 D compressors are equipped with a cover lid safety switch.**

**It cuts-off the drive engine and /or prevents starting the compressor unit when the cover lid is being opened / open.**



**Safety Switch Cover Lid LW 450 D**


---

## Oil Pump Service

The oil pump has an integrated plastic filter which needs to be cleaned every 1,000 working hours

### How to clean the oil filter:

- Remove 4 bolts securing the oil pump cover (see picture)
- Remove oil pump cover
- Remove blue plastic oil sieve
- Clean oil sieve with compressed air
- Check if oil sieve is undamaged (replace if necessary)
- Clean sealing surfaces of main housing and cover
- Check cover gasket (replace if necessary)
- Check O-ring (replace if necessary)
- Place gasket and O-ring on top cover
- Place oil sieve on main housing (make sure **UP** marking is facing upwards)
- Reassemble oil pump and fasten cover bolts




Remove 4 bolts of top cover



Oil Sieve

### Parts of Oil Pump:

- 1) Oil Pump Main Housing
- 2) Oil Sieve (blue coloured plastic)
- 3) Cover bolts
- 4) O-Ring
- 5) Oil Pump Cover
- 6) Cover Gasket



## Pressure maintaining and non-return valve

*The combined pressure maintaining / non-return valve is located in the system directly after the final filter housing*



*Pressure Maintaining Valve*

### Pressure maintaining valve

The pressure maintaining valve serves to keep the pressure in the final filter housing at a minimum of 150 to 180 bar. This high pressure creates more condensation in the separator/housing that can be mechanically removed (opening the drain valve) before the air is finally purified in the final filter, thus extending the life of the filter cartridge.

When the compressor is started, the pressure will build up in each stage as the compressor runs. The pressure in the final filter housing will increase until the pressure maintaining valve set pressure is reached. As a result of this function, the filling pressure gauge will not show any pressure for approx 1 min after the compressor is started and no air will flow out of the filling valve if opened.

Once the pressure maintaining valve opens, the pressure gauge will respond by climbing quite rapidly (within a few seconds) to the set pressure of the pressure maintaining valve (default 150 to 180 bar).

### Adjusting the pressure maintaining valve:

- Open the filling valve to vent the system completely, close the filling valve (*Pressure gauge reads 0 bar*)
- Start the compressor
- Monitor the pressure gauge
- The valve will open and the pressure the gauge climbs to quickly to the set pressure, this should be 150 – 180 bar
- If the pressure setting is outside this valve, adjust the pressure maintaining valve as follows:

**Increase the pressure setting:**

- Stop the compressor and open the drain valves
- Open the filling valve to vent the system after the pressure maintaining valve (*Pressure gauge reads 0 bar*)
- Loosen the locking screw on the pressure maintain valve
- Using a suitable tool, screw the valve setting screw clockwise to increase the spring tension
- Start the compressor and check the pressure setting, adjust as necessary
- Re-tighten the locking screw
- Check the pressure maintaining opening pressure once again

**Decrease the pressure setting:**

- Stop the compressor and open the drain valves
- Open the filling valve to vent the system after the pressure maintaining valve (*Pressure gauge reads 0 bar*)
- Loosen the locking screw on the pressure maintain valve
- Using a suitable tool, screw the valve setting screw anti-clockwise to decrease the spring tension
- Start the compressor and check the pressure setting, adjust as necessary
- Re-tighten the locking screw
- Check the pressure maintaining opening pressure once again

**Warning:**

If the pressure maintaining valve is set at a higher pressure than the maximum working pressure, the final safety valve will blow off before the pressure maintaining valve opens, the pressure gauge will read 0 bar!

After repair work where the pressure maintaining valve is not yet adjusted, the basic setting is the setting screw approx 3 turns in to the housing.

**Non-return valve**

The non-return valve is located in the system after the pressure maintaining valve and prevent air from flowing back from the filling lines into the final filter housing/compressor block. The non-return valve is operating correctly if the pressure gauge on the filling valve remains constant when the drain valves on the compressor are opened.

---

## V-Belt

The compressor block is driven by the engine via V-belt.  
Check V-belt condition / tension at least once a month.

*In case of high V-belt wear, check the following:*

- V-belt tension
- Check pulley grooves for marks / scratches / damage
- Check if pulley grooves are free from oil / grease

### ***How to tension the V-belt***

Attention: Do not work on hot compressors / engines

- Stop compressor and wait until it has cooled down
- Slightly loose nuts of motor flange (*use 19mm spanner / socket*)
- Adjust motor tensioning bolt until correct V-belt tension is achieved (*located next to the motor flange*)  
- use 19mm spanner / socket
- Tighten nuts of motor flange
- Check tension of V-belt (*readjust if necessary*)

---

### **ATTENTION:**

Insufficient V-belt tension leads to higher vibrations and increases the noise level of the compressor unit.

Replace faulty V-belts immediately.

Always use V-belts of right length / specification.

Make sure V-belt groove is free of oil / moisture and undamaged

---



# FILTERCHANGE

## Stationary L&W Compressors

### Filter cartridge change

- Unscrew the filter housing cap anti-clockwise, first with the special cartridge key and later by hand (1)
- Place the other end of the cartridge key in the filter cartridge in the filter housing (2)
- Unscrew the filter cartridge anti-clockwise and pull the cartridge out of the housing (3)
- Check O-ring for wear and grease thread of top cap
- Open the sealing of the new filter cartridge and use the cartridge key to place it in the filter housing (3)
- Screw in the new filter cartridge clockwise with the cartridge key hand tight (2)
- Refit the cap of the filter housing clockwise, first by hand and than by the filter key, hand tight (1)
- Close the drain valve of the separator / filter housing if only the hand operated drain is mounted.

The filter cartridge replacement is now completed, ensure that the saturated filter cartridge is disposed of correctly at an approved waste point.





## L&W PURACON Humidity Controller

### Contents

For your safety-----	2
Intended Use-----	2
Regulations-----	2
Description-----	2
Installation -----	3
Sensor -----	4
Operation -----	5
Sensor calibration-----	6
Removal of sensor and display for return -----	6
Technical data -----	7

Lenhardt & Wagner GmbH  
An der Tuchbleiche 39  
D-68623 Lampertheim - Hüttenfeld  
Germany  
[www.lw-compressors.com](http://www.lw-compressors.com)

## ***For your safety***

For correct, effective and safe use of the equipment and to avoid hazards it is essential to read and adhere to the following recommendations.

## **Strictly follow the instructions for use**

Any use of the equipment requires full understanding and strict adherence of these instructions. The apparatus is only to be used for purposes specified here. Attention is drawn to the specific instructions for use of compressor and/or compressed air accordingly.

## **Maintenance**

The apparatus must be inspected, calibrated and serviced by specialists at regular intervals (and a record kept). We recommend obtaining a service contract with our authorized Service. Repair or calibration should only be carried out by authorized Service technicians

## **Liability for correct function or damage**

The liability for the correct function of apparatus is irrevocably transferred to the owner or operator to the extent that if the equipment has been serviced or repaired by personnel not employed or authorised by Lenhardt & Wagner or when the equipment was used in a manner incompatible with the intended use. Lenhardt & Wagner cannot be held responsible for damage caused by non-compliance with the recommendations given above. The warranty and liability provisions of the terms of sale and delivery of Lenhardt & Wagner are affected by the recommendations given above.

Lenhardt & Wagner GmbH

## ***Intended Use***

The instrument is for monitoring the humidity of air/gas in a filling system such as a breathing air filling station using high pressure compressors.

Correctly installed and connected, the instrument monitors and displays the moisture content in a high pressure pipeline. The instrument can be used as a visual reference for the state of purification filters, as an audio alarm for exceeding pre-set moisture levels, or as a safety device for cutting out off a compressor when a pre-set moisture level is exceeded.

## ***Regulations***

Regulations for the quality of breathing are relevant, as are regulations for the installation and operation of high pressure gas installations and cylinders. In particular, the EN 12021 stipulates a limit of 25 mg/m<sup>3</sup> moisture in breathing air as measured from a compressor.

## ***Description***

The instrument consists of the following components which make up the standard scope of delivery:

---

## Display unit

The display unit consists of a housing with an LCD display, 3 quick reference LEDs, a mains power cable, an orange sensor cable and two buttons on the front for Mode and Rest.

The orange sensor cable should only be connected / disconnected when the power supply is off (unplugged). Cables up to 30m length are available as accessories.

The power supply cable is for use with a standard 230V CE socket with Earth. Other voltages available on request.

The LCD display shows the present moisture level in  $\text{mg}/\text{m}^3$  and/or self test and alarm messages.

The 3 quick reference LEDs give a visual indication of the moisture level (factory settings):

- Green  $<20 \text{ mg}/\text{m}^3$
- Yellow  $21\text{-}25 \text{ mg}/\text{m}^3$
- Red  $>25 \text{ mg}/\text{m}^3$  (cut-off or alarm relay is activated)



## Sensor housing

The cylindrical sensor housing consists of two halves screwed into each other and sealed with an O ring. The sensor housing contains the highly sensitive sensor that monitors the moisture content. If a filter is not changed when the display indicates, then water droplets may enter the sensor housing causing faults in the system.



## Blind plug

The stainless steel blind plug that is sealed with an o-ring is used to block the lower housing body when the upper body is removed for repair/service. This ensures that the filling station can still function without the humidity controller.



## Instructions for use

These instruction form part of the scope of delivery

### **Installation**


**Warning:** Before any work is carried out, isolate the power supply to prevent injury.

The puracon may be already installed in a compressor or a filling station, or may need to be installed in an existing system as follows:

## Display

Remove the two plastic covers from the front of the display, unscrew the four screws which join the front cover and the rear cover.

When the display is opened, the two cables can be unplugged from the printed circuit board (PCB) and the front cover including PCB placed in a safe place.



The rear cover can now be mounted onto a wall or panel with 4 screws (not included). The two cables are located on the left hand side.



Plug in the cables onto the PCB without using excessive force and refit the front cover and the two plastic strips.

## Sensor

The sensor housing should be vertically mounted in the high pressure pipeline after a non return/pressure maintaining valve. A non return valve is recommended in the outlet of the housing towards the filling panel. The connections should be made with suitable hermetic connections by a qualified technician. There is no particular direction of flow.

Care is to be taken that no burrs or debris remains in the pipeline.



## Sensor cable

The sensor cable plug has a guide inside for the sensor housing socket to prevent incorrect connections. Do not use excessive force when plugging the cable in, and screw down the plug finger tight.



**Warning:** Do not connect/disconnect the sensor cable when the power supply is on.

## Power supply

If the Puracon is to be connected to a standard electric socket, simply plug in the CE plug into an earthed socket. The standard units require 210 – 250V AC, 40-60 Hz. Other voltages available on request.

If the Puracon is to be connected into a compressor's power supply, the cable in the electrical distribution box of the compressor is to be shielded, the shielding can be connected to a suitable metal connection. A qualified electrician is recommended for carrying out this work.

## Electrical connections

- 1 PE Earth green/yellow cable)
- 2 L1 240V AC or +12V / +24V (special version)
- 3 Neutral or Return in -12V / -24V (special version)
- 4 Free
- 5 Off (Relay switched. Motor off)
- 6 On (Relay switched, motor can be started) Relay voltage <40V AC or <2V DC
- 7 Common connection

## Operation

When the power supply is turned on, or when the compressor is turned on, the puracon will start a self test sequence.

## Language selection

Press **Reset**

Press and hold **Mode**, press **Reset**

When a Peep is heard and the display goes blank, release **Mode**

“**Language**” will appear in the display

After hearing a peep, press **Mode** and keep it pressed

When the desired language appears in the display, release **Mode**

A long peep signal the end of the selection.

## Display

The display will show the actual humidity in the system and display the value in mg/m<sup>3</sup> on the LCD accompanied by an LED as follows.

After the compressor has been standing for some time or after a filter change, there will be remaining moisture in the system that will be displayed as a value higher than 20 mg/m<sup>3</sup> with a yellow or red LED. When the compressor air starts to flow through the system, the remaining moisture will be flushed out of the system and the moisture level will reduce.

## Errors

If an error is shown in the display, the unit can be re-set by pressing and then releasing the **Reset** button. The system will restart and carry out a self test. Pressing **Reset** at any time will return the unit to the normal monitoring mode.

The following errors may appear in the display:

Error 1 Moisture, defective or contaminated sensor

Error 2 Moisture, value outside normal parameters or out of calibration

Error 3 -

Error 4 Default is missing, data loss in memory, cross connection

Error 5 Sensor cable is defective or broken, no monitoring

If this error remains, replace the sensor cable.

Error 10 Voltage for sensor supply <7 volt> 10 volt

Error 11 Voltage for processor supply <4.7 volt>5.3 volt

Error 12 12V DC Supply <10 volt> 14 volt

Error 13 15V AC/DC transformer <13 volt> 17 volt

If the error remains on the display after reset, then the unit must be returned to an authorised repair facility.

## Sensor calibration

The sensor is subject to a natural aging process with an expected life of approx. 6 years. The sensor should be calibrated every 2 years. This calibration requirement is not necessary if independent air/gas quality assurance measures are taken (at least once a year).

## Removal of sensor and display for return

For the regular calibration or if the unit has a defect and must be sent back for repair, the unit can be dismantled as follows:

### Sensor cable

Ensure the power supply is isolated and unplug the sensor cable from the sensor housing.

### Sensor housing

Ensure that the sensor housing is vented and pressure free. The upper part of the sensor housing can be unscrewed from the lower housing using a suitable "C" spanner. Fit the blanking plug into the lower housing to seal the system and allow continued use (without humidity monitoring).

### Display

Remove the two plastic strips from the front of the display, remove the 4 screws and pull the front display half away from the rear half carefully.

Unplug the two (or three) cables from the PCB.

Return the front half of the display and the upper sensor unit to an authorised repair facility or to a Lenhardt & Wagner facility. It is not necessary to include the cables with the returned unit.

---

## **Technical data**

### **Display**

Dimensions (L x W x H):	120 x 120 x 60 mm
Installation dimensions:	150 x 120 x 60 mm
Weight	approx. 800 g
Voltage (standard unit)	210 - 250 V AC 6VA
Frequency	40 - 60Hz
Protection class	IP65
Relay	<40V DC/<2A DC

### **Sensor**

Dimensions ( L x Ø):	95 x 45 mm
Installation dimensions:	95 x 100 mm
Weight:	approx. 800 g
Maximum pressure:	330bar
Protection class:	IP65
Working temperature	+5 - +50°C

---

Lenhardt & Wagner GmbH  
An der Tuchbleiche 39  
D-68623 Lampertheim – Hüttenfeld


Germany  
[www.lw-compressors.com](http://www.lw-compressors.com)

---



## OIL CHANGE INSTRUCTIONS

### LW 300 / LW 450 / LW 570 / LW 720 / LW 1300





For the periodic oil change, please follow the time schedule of the instruction manual;

Only use original L&W synthetic oil type 9001 (1 ltr bottle, order no.: 000001).

Before changing the oil, be sure the compressor is switched off and cannot be inadvertently started. Disconnect it from the power supply or by switch off the starter of the gasoline or Diesel engine.

To conduct an oil change, the temperature of the oil must be at least +20°C to allow it to flow easily. In cold climates, the compressor should run first for about 15 minutes, dependent on the ambient temperature.



The picture above is showing the easy way of oil refilling by using a funnel placed on the oil drain hose.

#### Oil change

- Unscrew the filling cap anti-clockwise (1)
- Remove the oil drain hose from its holder (2)
- Unscrew the drain hose cap anti-clockwise (3)
- Hold the drain hose over a container for waste oil and open the drain valve (4)
- Let the oil drain completely, close valve (4), screw on plug (3) and relocate the hose
- Refill the block with original L&W compressor oil (approx. 1.8 ltr) by using a funnel
- The indicator glass (5) should be filled up to the top level! - **DO NOT OVERFILL WITH OIL!!**
- Refit the oil filler cap

The oil change is now completed, **ensure the filling cap (1) is securely refitted.** The schedule in the maintenance manual will indicate the next oil change or the ECC display. Ensure the waste oil is disposed of correctly at an approved waste oil point.



---

## Service, Repair and Maintenance

---

All repair, service and maintenance work is to be carried out when the compressor is stopped, isolated from the power supply and pressure free.

The unit is to be regularly checked for leaks of air/oil, air leaks can be localised using a leak detector or spray

It is recommended that only authorised L&W service technicians carry out repair and service on the bearing of the compressor (crankshaft and connecting rods)

---

### Conservation / storage of the compressor:

If the compressor is not to be used for an extended period of time, we recommend the following conservation work is carried out before the storage:

- ✓ Run the compressor at 200 bar for approx ten minutes (control the flow with the filling valve to maintain the pressure).
  - ✓ Replace oil.
  - ✓ Open filling valve(s) and run the compressor for a few minutes.
  - ✓ Stop the compressor and open the drain valves.
  - ✓ Close the filling valves.
  - ✓ Open the final filter housing and lubricate the O-Ring with a food grade grease or silicone grease.
  - ✓ Store the compressor in a cool dry place free from dust and contamination. A cover is recommended as long as condensation can be avoided.
- 
- ✓ Fuel Driven Units only: Fill up fuel tank to top level to avoid corrosion.
- 

### De-conservation, commissioning:

*After the compressor has been stored, the following steps are to be taken:*

- ✓ If the compressor has been stored for more than 12 Months, we recommend replacing the oil before use.
- ✓ Replace the final purification filter.
- ✓ Check oil level.
- ✓ Inspect the condition of the vee belts, replace if necessary
- ✓ Inspect the filling hoses visually for signs of deterioration, replace as necessary.
- ✓ Open the filling valves and run the compressor for approx 10 minutes with the filling valves open.
- ✓ Close the filling valves and allow the compressor to build up to working pressure.
- ✓ Check the correct safety valve setting and/or pressure switch setting (option).
- ✓ Check all connections and pipe work for leaks.

Once the above steps are completed to satisfaction, the unit is ready to use.

---

M A I N T E N A N C E   L I S T

# L W 4 5 0 D

Routine Service	Intervals	Qty.	Order No.
Replace filter cartridge	every 33 working hours (@ +20°C)	1	00002
Check oil level	before each day of use		
Oil changes	1 <sup>st</sup> after 25 working hours 2 <sup>nd</sup> after 50 working hours 3 <sup>rd</sup> after 200 working hours thereafter every 200 working hours - but at least once a year	2200 ml	00001  (1 litre)
Replacing air inlet filter	Depends on degree of pollution - but at least once a year	1	000170
Check V-belt	every 200 working hours	1	
Replace in- & outlet valves	every 6,000 working hours	1 <sup>st</sup> stage: 1 2 <sup>nd</sup> stage: 1 3 <sup>rd</sup> stage: 1	000259 000256 000510
Check pressure maintaining / non-return valve	every 200 working hours		
Check safety devices	at least once a year		
Check pressure pipes for air leaks	every 200 working hours		
Clean pressure pipes	Depends on degree of pollution - but at least once a year		
Check filling hoses for damage	before each use - once a year by an expert		
Replace oil suction hose	every 5,000 working hours	1	003109
Clean sieve of oil pump	every 1,000 working hours		
Replace sintered filter of condensate valve	after 1,000 working hours - thereafter every 5,000 working hours	1	000188
Replace sintered filter of water-separators	every 1,000 working hours	2 1	000184 000173

M A I N T E N A N C E   L I S T

**LW 450 D**

Routine Service	Intervals	Qty.	Order No.
-----------------	-----------	------	-----------

Clean oil / water-separators and check for corrosion	every 1,000 working hours		
Check connections and fixings for correct torque	after 15 working hours - thereafter every 500 working hours		
Replace 2 <sup>nd</sup> and 3 <sup>rd</sup> stage small end roller bearings	every 4,000 hours	2	003836



Symptom	Problem	Trouble Shooting
<b>Final pressure is not reached</b>	Connections leaking	Re-tighten, clean and/or replace
	Final pressure safety valve blows off	Replace
	Cooling pipe leaking	Replace
	Condensation drain valves	Check tightness, clean and/or replace
	Final pressure switch cuts off (option)	Re-set final pressure cut off
<b>Compressor vibrates excessively</b>	V-Belt tension insufficient	Tighten V-Belts
	Compressor block and/or prime mover mounting screws loose	Re-tighten
	Shock absorbing feet worn down	Replace
	Uneven surface	Move compressor accordingly
<b>Compressor overheats</b>	Inlet filter cartridge blocked	Replace
	Ambient temperature too high	Improve ambient conditions or run for shorter periods
	Cooling air feed/exhaust not sufficient	Adhere to the installation data
	Inlet hose too long	Reduce the length and/or increase the diameter
	Inlet hose diameter too small	Increase diameter
	Compressor turning in the wrong direction	Ensure correct rotation (phase)
	Suction/pressure valve blocked	Clean and/or replace
<b>Safety valve blows off</b>	Suction / pressure valve in the following stage defect	Clean and/or replace
	Sinter filter in the following stage blocked	Replace
	Safety valve leaks	Replace (do not tamper)
<b>Air tastes of oil</b>	Molecular carbon filter needs replacing	Replace
	Incorrect compressor oil	Use only authorised oil type
	Non conform type of filter	Replace with correct filter
	Cylinders and / or piston rings worn	Replace
<b>Delivery rate too low</b>	Suction/pressure valve blocked	Clean and/or replace
	Cylinder / piston rings worn	Replace
	Also see section „final pressure is not reached“	
<b>Automatic condensation drain not functioning (Option)</b>	Solenoids defect	Replace
	Cable/wiring defect	Repair
	Timer defect	Replace
	Sinter filter from pneumatic valve blocked	Replace
	Piston in the pneumatic valve blocking	Dismantle pneumatic valve
<b>Automatic condensation drain operates between cycles</b>	Pilot pressure for pneumatic valve too low	Replace suction/pressure valve / safety valve
	Piston seat in the pneumatic valve damaged/contaminated	Clean / Replace
	Timer settings incorrect	Set default settings



Symptom	Problem	Trouble Shooting
<i>(Option)</i>	Timer defective	Replace
<b>Compressor switches off before final pressure is reached</b> <i>(Option)</i>	Final pressure switch not properly set	Reset
	Pressure maintaining valve set too high	Reset
	Fuse/breaker tripped	Refer to the correct fuse ratings for the supply
<b>Filter cartridges times too short</b>	Pressure maintain valve set too low	Reset to 170 bar
	Non conform type of filter	Use only correct filters
	Shelf life exceeded	Adhere to date of expiry
	Packing damaged and / or filter packing opened too long before use	Store properly and open immediately before use
	Ambient temperature too high	Ensure correct and sufficient cooling air feed and exhaust
	Cylinder / piston rings worn	Replace
<b>Excessive oil consumption</b>	Cylinder / piston rings worn	Replace
	Incorrect compressor oil	Use only authorised oil type
	Operating temperature too high	Adhere to operating parameters
	Oil leak in the compressor block	Check relevant components especially shaft seal and replace/re-tighten



## Tightening Torques

LW 160 E	LW 190 B	LW 225 E V3	LW 245 B V3
LW 170 D - Nautic	LW 170 E - Nautic	LW 200 E - Nautic	

<b>Cylinder Head Bolts</b>	1 <sup>st</sup> Stage	22 - 24 Nm
<b>Cylinder Head Bolts</b>	2 <sup>nd</sup> & 3 <sup>rd</sup> Stage	28 Nm
<b>Nuts M10</b>	(8.8)	44 Nm
<b>Cooling Fan Bolts</b>	(8.8)	20 Nm
<b>Slider Guide Bolt</b>		10 Nm

LW 230 E / ES	LW 280 E / ES
---------------	---------------


<b>Cylinder Head Bolts</b>	1 <sup>st</sup> Stage	37.5 Nm
<b>Cylinder Flange Bolts</b>	1 <sup>st</sup> Stage	35 Nm
<b>Cylinder Head Bolts</b>	2 <sup>nd</sup> Stage	30 Nm
<b>Cylinder Head Bolts</b>	3 <sup>rd</sup> Stage	30 Nm
<b>Guide Cylinder Flange Bolts</b>	2 <sup>nd</sup> & 3 <sup>rd</sup> Stage	41 Nm
<b>Block Fixing Bolts M10</b>	(8.8)	44 Nm

LW 450 D / E / ES	LW 570 E / ES
-------------------	---------------



<b>Cylinder Head Bolts</b>	1 <sup>st</sup> Stage	37.5 Nm
<b>Cylinder Head Bolts</b>	2 <sup>nd</sup> Stage	32 Nm
<b>Cylinder Head Bolts</b>	3 <sup>rd</sup> Stage	32 Nm
<b>Cylinder Head Bolts</b>	4 <sup>th</sup> Stage	32 Nm
<b>Cylinder Flange Bolts</b>	1 <sup>st</sup> Stage	35 Nm
<b>Cylinder Flange Bolts</b>	2 <sup>nd</sup> Stage	35 Nm
<b>Cylinder Flange Bolts</b>	3 <sup>rd</sup> Stage	35 Nm
<b>Block Fixing Bolts M10</b>	(8.8)	44 Nm

# FLOW DIAGRAM

- 1 Intake Filter
- 2 1st Pressure Stage
- 3 Condensate Drain Hose
- 4 Safety Valve 1st Stage
- 5 Heat Exchanger
- 6 Condensate Valve
- 7 Oil- / Waterseparator
- 8 2nd Pressure Stage
- 9 Condensate Drain Hose
- 10 Safety Valve 2nd Stage
- 11 Heat Exchanger
- 12 Condensate Valve
- 13 Oil- / Waterseparator
- 14 3rd Pressure Stage
- 15 Condensate Drain Hose
- 16 Safety Valve 3rd Stage
- 17 Heat Exchanger
- 18 Oil- / Waterseparator
- 19 Pneumatic Condensate Valve
- 20 Solenoid
- 21 Condensate Release Final Stage
- 22 Silencer
- 23 Pressure Maintaining Valve
- 24 Non-return Valve
- 25 High Pressure Hoses
- 26 Pressure Gauge
- 27 Control Pressure 2nd Stage
- 28 Tank Connectors
- 29 High Pressure Outlet Hose (Option)



**LW 450 D**  
 LENHARDT & WAGNER GMBH




Outlet  
Length of Filling Hose: 2,000mm

## LW 450 D

Overall Dimensions

LENHARDT & WAGNER GMBH



Lenhardt & Wagner  
Kompressor


Kom.-Nr. 194061\_4  
Pl.-Nr. 94047\_4

Lead-In & Pull-Magnet,  
Partial Load /  
Full Load

LW 450 D  
Hatz Engine

Blatt  
001  
von  
044

Gez.: R. Deibert    Gepr.: G. Buhler    02. SEP. 1936



Lenhardt & Wagner  
Kompressor


Kom. Nr. 194061.4  
Pl. Nr. 94062.4

Control

Type : LW 450 D  
Hatz Engine

Blatt 002  
von 004

Gez.: R. Gelbert    Gepr.: H. Buhler    02. SEP. 1936



Solenoid 1  
12 V

Solenoid 2  
12 V

Solenoid 3  
12 V

Switch  
Partial Load /  
Full Load

Manual Switch  
Valves Open

Hour Meter

Page 3

Lenhardt & Wagner  
Kompressor


Ken.-Nr. 194861\_4  
Pl.-Nr. 94857\_4

Control  
Solenoids


Type : LW 450 D  
Hatz Engine


Blatt  
983  
vin  
904

Gez.: R. Delbert    Gepr.: U. Bühler    02. SEP. 1996



Kompressor: LW 450 D  
Compressor: LW 450 D





004606

Bg: Filter  
Ass. Filter


002371


004608

Bg: Puracon  
Ass. Puracon


Bg: Sicherheitsventil  
Ass. Safety valve

004607





Bg: Schwungrad  
Ass. Flying Wheel




Bg: Filter  
Ass. Filter

Bg: Manometer  
Ass. Manometer

Bg: Kühler 2. Stufe  
Ass. Cooler 2nd stage


Bg: Kühler 3. Stufe  
Ass. Cooler 3rd stage

# LW 450 D



Kompressor: LW 450 D  
Baugruppe: Manometer (0-400 bar)  
Assembly: Pressure gauge (0-400 bar)


000662






Kompressor: L&W 450 D  
Baugruppe: Kurbelwelle  
Assembly: Crankshaft

001207




Kurbelweele komplett:  
Crank shaft complete:  
000269

Kompressor: LW 450 D  
Baugruppe: Kolben komplett 1. Stufe  
Assembly: Piston complete 1st stage




Kompressor: L&W 450 D  
Baugruppe: Kolben Stufe 2  
Assembly: Piston 2nd Stage




Kompressor: L&W 450 D  
Baugruppe: Kolben-Stufe 3  
Assembly: Piston 3rd stage

A (5:1)



000365



A



2x Detail A

000366


4507026 a (2x)



000373




Kompressor: LW 450 D  
Baugruppe: Schwungrad  
Assembly: Flywheel






Kompressor: L&W 450 D  
Baugruppe: Kühler 2. Stufe  
Assembly: Cooler 2nd stage




Kühlspirale 3. Stufe  
Cooling Pipe 3rd Stage




Kompressor: L&W 450 D  
Baugruppe: Ventil 1. Stufe  
Assembly: Valve 1st Stage

000369  
(complete)



Kompressor: L&W 450 D  
Baugruppe: Ventil 2. Stufe  
Assembly: Valve 2nd Stage


4507065  
(complete)




Markierungen zur  
Deckung bringen

Align Marks


Kompressor: L&W 450 D  
Baugruppe: Ventil 3. Stufe  
Assembly: Valve 3rd Stage




Kompressor: LW 450 D  
Baugruppe: Ölpumpe  
Assembly: Oil pump




Kompressor: L&W 450 D  
 Baugruppe: Wasserabscheider Stufe 1  
 Assembly: Water separator 1st Stage



Kompressor: L&W 450 D  
Baugruppe: Wasserabscheider 2. Stufe  
Assembly: Water separator 2nd Stage




Kompressor: L&W 450 D  
Baugruppe: Filterpatrone  
Assembly: Filter cartridge




Kompressor: L&W 450 D

Baugruppe: Öl-/ Wasserabscheider Stufe 3


Assembly: Oil-/ Water separator 3rd Stage



Kompressor: L&W 450 D  
Baugruppe: Druckschalter  
Assembly: Pressure Switch




000203




000751

000765

000766




Ansaugfilter komplett:  
Intake filter complete:  
000171




000201

000170


Kompressor: L&W 450 D  
 Baugruppe: Kondensat Ablassventil  
 Assembly: Condensat drainage valve



Kompressor: LW 450 D  
Baugruppe: Ölablassschlauch - Kompressor  
Assembly: Oil Drain Hose - Compressor





Kompressor: LW 450 D  
Baugruppe: Ölablassschlauch - Motor  
Assembly: Oil Drain Hose - Engine




Kompressor: L&W 450 D  
 Baugruppe: Sicherheitsventil  
 Assembly: Safety valve

Druck	SV-Ventil mit CE-Prüfung	SV-Ventil mit TÜV-Prüfung
225 bar	001814	000553
250 bar	001815	000554
285/300 bar	-----	000555
330 bar	001816	000556
350 bar	001817	000557






Batterie LW 450 D  
Battery LW 450 D



Baugruppe: Motorplatten  
Assembly: Engine Base Plates




LW 450 D

HATZ Diesel Engine

Type: 1D81C

005065





DESCRIPTION	BENENNUNG	Order No. Bestell-Nr.
<b>Synthetic Compressor Oil, Volume: 1 Litre</b>	<b>L&amp;W synthetisches Kompressoren Öl Inhalt: 1 Liter -</b>	<b>000001</b>
<b>Filter Cartridge (Breathing Air) Active Carbon / Molecular Sieve</b>	<b>Filterpartone (Atemluft) Molekularsieb / Aktivkohle</b>	<b>000002</b>
<b>Pressure Maintaining Valve</b>	<b>Druckhalte-/ Rückschlagventil</b>	<b>000169</b>
<b>Air Intake Cartridge</b>	<b>Ansaugfilterpatrone</b>	<b>000170</b>
<b>Intake Filter Housing c/w filt</b>	<b>Ansaugfilter kompl. mit Filtereinsatz</b>	<b>000171</b>
<b>Plastic Air Deflector</b>	<b>Halteteller</b>	<b>000172</b>
<b>Sintered Filter</b>	<b>Sinterfilter</b>	<b>000173</b>
<b>Twist Disk</b>	<b>Drallscheibe</b>	<b>000174</b>
<b>Cover</b>	<b>Deckel</b>	<b>000175</b>
<b>Water Deflector, Plastic</b>	<b>Wasserabweiser</b>	<b>000177</b>
<b>Silencer</b>	<b>Schalldämpferelement Wasserabscheider 3. Stufe</b>	<b>000178</b>
<b>Water Separator c/w bracket</b>	<b>Filtergehäuse kompl. mit Halterung</b>	<b>000182</b>
<b>Filter Protector</b>	<b>Wasserabweiser</b>	<b>000183</b>
<b>Siltered Filter</b>	<b>Sinterfilter</b>	<b>000184</b>
<b>Plate</b>	<b>Halteteller</b>	<b>000185</b>
<b>Twist Disk</b>	<b>Drallscheibe</b>	<b>000186</b>
<b>Sintered Filter</b>	<b>Sinterfilter für Kondensatventil</b>	<b>000188</b>



DESCRIPTION	BENENNUNG	Order No. Bestell-Nr.
<b>Piston c/w O-Ring</b>	<b>Steuerkolben mit O-Ring Pneumatisches Kondensatablassventil</b>	<b>000191</b>
<b>Repair Kit Condensate Valve</b>	<b>Reparatursatz Pneumatisches Kondensatablaßventil</b>	<b>000194</b>
<b>Inlet Jet Screw c/w O-Ring</b>	<b>Düsenschraube mit O-Ring Pneumatisches Kondensatablassventil</b>	<b>000196</b>
<b>Plug c/w Seal Ring</b>	<b>Stopfen mit Dichtung Pneumatisches Kondensatventil</b>	<b>000197</b>
<b>Body PCV</b>	<b>Gehäuse Pneumatisches Kondensatablassventil</b>	<b>000198</b>
<b>Pneumatic Condensate Valve</b>	<b>Kondensatablassventil, komplette Baueinheit</b>	<b>000199</b>
<b>Adapter Flange Oil Pump</b>	<b>Ölpumpenhalteflansch zur Befestigung der Ölpumpe am Kompressor</b>	<b>000200</b>
<b>Adapter Inlet Filter Housing</b>	<b>Adapter für Luftansaugfilter</b>	<b>000201</b>
<b>Pressure Switch 50-350bar</b>	<b>Enddruck Druckschalter, Pmax: 350 bar</b>	<b>000203</b>
<b>Oil Pump, complete unit</b>	<b>Ölpumpe kompl.</b>	<b>000204</b>
<b>Drive Flange Oil Pump</b>	<b>Ölpumpenantriebsflansch</b>	<b>000208</b>
<b>Safety Valve 1st Stage, 8 bar</b>	<b>Sicherheitsventil kompl. G3/8" 1. Stufe</b>	<b>000220</b>
<b>Safety Valve 2nd Stage, 50 bar</b>	<b>Sicherheitsventil kompl. G3/8" 2. Stufe</b>	<b>000225</b>
<b>Base for Safety Valve</b>	<b>Sockel für Sicherheitsventil</b>	<b>000233</b>
<b>Ball Bearing, Type 6308</b>	<b>Rillenkugellager 6308</b>	<b>000239</b>



DESCRIPTION	BENENNUNG	Order No. Bestell-Nr.
<b>Gasket, Guide cylinder</b>	<b>Dichtung Führungszylinder</b>	<b>000240</b>
<b>Gasket</b>	<b>Dichtung für Kurbelwellen - Flanschdeckel</b>	<b>000241</b>
<b>Thrust Washer &amp; Circlip</b>	<b>Sicherungen &amp; Scheiben</b>	<b>000242</b>
<b>Bearing Bush</b>	<b>Lagerring</b>	<b>000243</b>
<b>Shaft Seal</b>	<b>Wellendichtring</b>	<b>000244</b>
<b>Oil Splash Ring</b>	<b>Ölring</b>	<b>000248</b>
<b>Copper Washer</b>	<b>Dichtring</b>	<b>000250</b>
<b>Lower Valve Gasket, Copper</b>	<b>Untere Ventildichtung 2. Stufe (Kupfer)</b>	<b>000253</b>
<b>Upper Valve Gasket, Paper</b>	<b>Obere Ventildichtung 2. Stufe (Papier)</b>	<b>000254</b>
<b>Valve assembly 2nd Stage</b>	<b>Ventil 2. Stufe</b>	<b>000256</b>
<b>Upper Valve Gasket 1<sup>st</sup> Stage</b>	<b>Obere Dichtung Ventilplatte 1. Stufe</b>	<b>000257</b>
<b>Lower Valve Gasket 1<sup>st</sup> Stage</b>	<b>Untere Dichtung Ventilplatte 1. Stufe</b>	<b>000258</b>
<b>Conrod 1<sup>st</sup> Stage, compl.</b>	<b>Pleuel 1. Stufe kompl.</b>	<b>000267</b>
<b>Conrod 2<sup>nd</sup> &amp; 3<sup>rd</sup> Stage, c/w bearing</b>	<b>Pleuel 2. &amp; 3. Stufe kompl. mit Lager; Ø 16 x 22mm</b>	<b>000268</b>
<b>Crankshaft complete</b>	<b>Kurbelwelle kompl.</b>	<b>000269</b>
<b>Valve Head 2<sup>nd</sup> Stage</b>	<b>Ventilkopf 2. Stufe</b>	<b>000270</b>
<b>Valve Head 1<sup>st</sup> Stage</b>	<b>Ventilkopf1. Stufe</b>	<b>000271</b>
<b>Main Bearing Flange</b>	<b>Lagerdeckel</b>	<b>000273</b>



DESCRIPTION	BENENNUNG	Order No. Bestell-Nr.
<b>Compression Cylinder 2nd Stage Ø42 mm</b>	<b>Zylinder 2. Stufe Ø 42 mm</b>	<b>000274</b>
<b>Piston 1<sup>st</sup> Stage Ø105mm</b>	<b>Kolben 1.Stufe, Ø105mm, LW 570</b>	<b>000359</b>
<b>Set Piston Rings Ø105mm</b>	<b>KolbenringsatzØ105mm, LW 570 1.Stufe</b>	<b>000360</b>
<b>Piston Pin Ø25x90mm</b>	<b>Kolbenbolzen LW 570, 1.Stufe Ø25x90mm</b>	<b>000361</b>
<b>Piston 2<sup>nd</sup> Stage Ø50mm</b>	<b>Kolben 2.Stufe, Ø50mm, LW 570</b>	<b>000362</b>
<b>Set Piston Rings Ø50mm 4pcs</b>	<b>KolbenringsatzØ50mm (4 Stück)</b>	<b>000363</b>
<b>Retaining Ring</b>	<b>Sicherungsring</b>	<b>000364</b>
<b>Set Piston Rings 3rd Stage</b>	<b>Kolbenringsatz 3.Stufe</b>	<b>000365</b>
<b>Piston Ø25mm</b>	<b>Kolben Ø25mm, LW570, Stufe 3</b>	<b>000366</b>
<b>In-&amp;Outlet Valve Ø122 mm</b>	<b>Saug- Druckventil Ø122mm LW 570, LW 720, 1.Stufe</b>	<b>000369</b>
<b>Piston Pin Ø20x40 mm</b>	<b>Kolbenbolzen LW 570, 2.Stufe Ø20x40mm</b>	<b>000373</b>
<b>Oil House</b>	<b>Rohrleitung Ölpumpe Einlass</b>	<b>000376</b>
<b>Top Cap Water Separator</b>	<b>Wasserabscheider Oberteil</b>	<b>000379</b>
<b>Brass Filter Adapter</b>	<b>Messing Adapter für Filterpatrone, 1,7/2,3Liter</b>	<b>000383</b>
<b>Jet Filter Housing</b>	<b>Düse Filtergehäuse</b>	<b>000384</b>
<b>Bracket Water Separator</b>	<b>Blechhalter Kondensatabscheider</b>	<b>000395</b>
<b>Nut M6</b>	<b>Mutter M6</b>	<b>000497</b>
<b>Washer A6</b>	<b>Unterlegscheibe, DIN 125 A6</b>	<b>000498</b>



DESCRIPTION	BENENNUNG	Order No. Bestell-Nr.
<b>Bolt M6x55mm</b>	<b>Zylinderschraube, M6x55 DIN912</b>	<b>000499</b>
<b>Spring</b>	<b>Feder für Druckhalteventil</b>	<b>000506</b>
<b>Cap PMV</b>	<b>Kappe für Druckhalteventil</b>	<b>000507</b>
<b>Gasket Ring USIT</b>	<b>USIT Ring, 13,7xØ20x1,5</b>	<b>000508</b>
<b>Allen Bolt</b>	<b>Innen-Sechskantschraube</b>	<b>000509</b>
<b>Lock Nut PMV</b>	<b>Mutter, Druckhalte-Rückschlagventil</b>	<b>000511</b>
<b>Set Bolt PMV</b>	<b>Schraube, Druckhalte-Rückschlagventil</b>	<b>000512</b>
<b>Spring Adapter PMV, alloy</b>	<b>Druckstück für Druckhalteventil, Alu, Federadapter Druckhalteventil</b>	<b>000513</b>
<b>Stud</b>	<b>Stift</b>	<b>000514</b>
<b>Main Body PMV, black</b>	<b>Gehäuse, Druckhalte-Rückschlagventil</b>	<b>000515</b>
<b>Seal Ring PMV</b>	<b>Nutring, 5x10x5/2,5 90° blau</b>	<b>000516</b>
<b>Coil Spring PMV</b>	<b>Feder, Druckhalte-/Rückschlagventil</b>	<b>000517</b>
<b>Brass Washer</b>	<b>Unterlegscheibe, Messing, 10x6x1</b>	<b>000518</b>
<b>Plastic Seal Piston PMV</b>	<b>Dichtkappe, Druckhalte-Rückschlagventil, Kunststoff schwarz</b>	<b>000519</b>
<b>Banjo Bolt PMV</b>	<b>Hohlschraube, Druckhalte-Rückschlagventil</b>	<b>000520</b>
<b>Bracket Heat Exchanger</b>	<b>Klemmschiene Wärmetauscher</b>	<b>000521</b>
<b>Lower Valve Gasket</b>	<b>Alu Dichtung, Saug- u. Druckventil unten, 3.Stufe LW</b>	<b>000533</b>



DESCRIPTION	BENENNUNG	Order No. Bestell-Nr.
	<b>570</b>	
<b>Upper Alloy Seal Ring</b>	<b>Alu Dichtring / Dichtung, Saug- &amp; Druckventil oben 3.Stufe 450/570</b>	<b>000540</b>
<b>In-&amp;Outlet Valve</b>	<b>Saug-Druckventil, komplett 570 3.Stufe</b>	<b>000544</b>
<b>Safety Valve TÜV 225 bar</b>	<b>Sicherheitsventil, TÜV Einstellbescheinigung Einstelldruck 225bar</b>	<b>000553</b>
<b>Safety Valve TÜV 250 bar</b>	<b>Sicherheitsventil, TÜV Einstellbescheinigung Einstelldruck 250bar</b>	<b>000554</b>
<b>Safety Valve TÜV 300 bar</b>	<b>Sicherheitsventil, TÜV Einstellbescheinigung Einstelldruck 300bar</b>	<b>000555</b>
<b>Safety Valve TÜV 330 bar</b>	<b>Sicherheitsventil, TÜV Einstellbescheinigung Einstelldruck 330bar</b>	<b>000556</b>
<b>Safety Valve TÜV 350 bar</b>	<b>Sicherheitsventil, TÜV Einstellbescheinigung Einstelldruck 350bar</b>	<b>000557</b>
<b>Ring Water Separator</b>	<b>Ring</b>	<b>000562</b>
<b>Container Water Separator</b>	<b>Druckbehälter</b>	<b>000563</b>
<b>Container Water Separator</b>	<b>Wasserabscheider-Behälter, 2.Stufe LW450</b>	<b>000564</b>
<b>Bracket</b>	<b>Halterung</b>	<b>000568</b>
<b>Repair Kit Solenoid</b>	<b>Reparatursatz</b>	<b>000594</b>
<b>Lock Nut, Solenoid</b>	<b>Klemmmutter Magnetventil</b>	<b>000599</b>



DESCRIPTION	BENENNUNG	Order No. Bestell-Nr.
Solenoid Coil NC 230V AC 40bar	Magnetspule NC 230V AC 40bar, ohne Stecker, TM30	000607
Solenoid NC 80 G1/4 230V	Magnetventil 2x1/4" 40bar, 230 V 50/60 Hz NC, Messing	000616
Engine Mounting	Gummi - Motorhalterungen	000623
PVC Hose for Bracket	PVC Schlauch, transparent, für Wärmetauscher	000624
Pipe Clamp 8mm –single, 1pair PVC	PVC - Rohrschelle für 8mm Rohr (einfach)	000628
Pressure Gauge, 0-400 bar	Manometer mit Befestigungsbügel, 0 - 400 bar	000662
Connection	Verschraubung GE 06PLR 1/4" ED	000712
T-piece Connection	Verschraubung TE 06 L, TE G1/8" / 6L	000716
Nut 06L	Mutter 06L	000732
Olive Seal 6mm	Schneidring SR 06 (Ø6mm)	000733
Connection	Verschraubung gerade	000735
Connection	Verschraubung Oil Pumpe Druckseite	000737
Connection	Einschraubverbindung gerade - Eingang	000738
Connection	Verschraubung, GE 08 L/1/4"kegelig	000739
Connection	Verschraubung, TE 08 LR/1/4"kegelig	000751
Connection	Verschraubung LE 08 LR T-Stück mit Einschraubgewinde G1/4" seitlich	000758
Connection	Verschraubung WE 08 PLR CFX, Einschraubverschraubung 1/4"	000761



DESCRIPTION	BENENNUNG	Order No. Bestell-Nr.
Olive Seal 8 mm	Schneidring 8 mm	000765
Nut 08L	Mutter für Verschraubung 8 L	000766
Nut 08S	Mutter M 08 S A3C	000767
Connection	Verschraubung TE 10L R1/4"	000793
Connection	Einschraubverbindung gerade - Eingang	000818
Connection	Verschraubung GE 15L M18x1,5	000819
Connection	90° Winkelverschraubung Auslasseite	000820
Nut 15L	Mutter für Verschraubung 15 L	000822
Olive Seal 15 mm	Schneidring 15 mm	000823
Plug	Verschlussstopfen VSTI R1/8" ED	000837
Plug	Verschlussstopfen VSTI R1/4" ED CFX	000838
Plug	Verschlussstopfen VSTI R3/8" ED	000839
Reducer	Reduzierung RED 10/06L, mit fester Mutter	000858
Olive Seal 18 mm	Schneidring 18 mm	000861
Nut 18L	Mutter für Verschraubung 18 L	000862
Ellbow Connection	90° Winkelverschraubung Ausgang	000863
Double Nipple	Doppelnippel G1/8"-1/4", 4F3MK4S	000892
A-Lock Connection	A-Lok Verschraubung ETM8-316, T-Stück für Ø8mm	000914



DESCRIPTION	BENENNUNG	Order No. Bestell-Nr.
	Rohr	
Reducer	Reduzierung, R1/4"xR1/8"	000924
Plug	Ölablassstopfen	000934
Pan Head Bolt	Flachkopfschraube M6x12mm DIN6912 8.8 ZN	000949
Hexagon Bolt	Sechskantschraube, M6x16, DIN933 8.8	000951
Hexagon Bolt	Sechskantschraube, M6x20, DIN933 8.8	000952
Allen Bolt	Zylinderschraube, M10x30mm DIN912 8.8 ZN	000967
Allen Screw	Zylinderschraube, M5x16mm DIN912 8.8 ZN	001005
Allen Screw	Zylinderschraube, M5x25mm DIN912 8.8 ZN	001007
Allen Screw	Zylinderschraube, M6x60mm DIN912 8.8 ZN	001011
Allen Bolt	Zylinderschraube, M5x45mm DIN912 8.8 ZN	001022
Allen Bolt	Zylinderschraube, M6x30mm DIN912 8.8 ZN	001027
Allen Bolt	Zylinderschraube, M6x16mm DIN912 8.8 ZN	001030
Allen Bolt	Zylinderschraube, M8x16mm DIN912 8.8 ZN	001039
Allen Screw	Zylinderschraube, M8x20mm DIN912 8.8 ZN	001040
Allen Screw	Zylinderschraube, M8x35mm DIN912 8.8 ZN	001043
Allen Screw	Zylinderschraube, M8x40mm DIN912 8.8 ZN	001044
Allen Screw	Befestigungsschrauben für Luftverteilerleiste	001048



DESCRIPTION	BENENNUNG	Order No. Bestell-Nr.
<b>Slotted Counter Sunk Screw</b>	<b>Senkkopfschraube mit Schlitz M5x16mm DIN963</b>	<b>001052</b>
<b>Allen Bolt</b>	<b>Zylinderschraube</b>	<b>001056</b>
<b>Allen Bolt</b>	<b>Innen-Sechskantschraube</b>	<b>001058</b>
<b>Allen Bolt</b>	<b>Innen-Sechskantschraube</b>	<b>001060</b>
<b>Counter Sunk Screw</b>	<b>Senkschraube, M6x20mm DIN7991 8.8 ZN</b>	<b>001075</b>
<b>Allen Bolt</b>	<b>Zylinderschraube</b>	<b>001085</b>
<b>Allen Bolt</b>	<b>Zylinderschraube</b>	<b>001088</b>
<b>Hexagon Screw</b>	<b>6-kant Schraube, M10x20mm DIN933 8.8 ZN</b>	<b>001099</b>
<b>Allen Bolt</b>	<b>Zylinderschraube</b>	<b>001100</b>
<b>Hexagon Screw</b>	<b>6-kant Schraube, M10x40mm DIN933 8.8 ZN</b>	<b>001102</b>
<b>Hexagon Bolt</b>	<b>Keilriemenspannschraube kompl. mit Mutter</b>	<b>001107</b>
<b>Fixing Bolt</b>	<b>Befestigungsschrauben für Motorgrundplatte</b>	<b>001129</b>
<b>Fixing Bolt</b>	<b>Befestigungsschrauben für Wasserabscheider 2. Stufe</b>	<b>001131</b>
<b>Hexagon Screw</b>	<b>6-kant Schraube, M12x25mm DIN933 8.8 ZN</b>	<b>001132</b>
<b>Hexagon Screw</b>	<b>Sechskantschraube für Riemenscheibe</b>	<b>001133</b>
<b>Nut M5</b>	<b>Mutter M5</b>	<b>001151</b>
<b>Lock Nut</b>	<b>Mutter M6</b>	<b>001156</b>



DESCRIPTION	BENENNUNG	Order No. Bestell-Nr.
<b>Domed Nut M6</b>	<b>Hutmutter, M6 DIN1587 ZN</b>	<b>001157</b>
<b>Nut M8</b>	<b>Mutter M8</b>	<b>001158</b>
<b>Nut M8</b>	<b>Mutter M8</b>	<b>001159</b>
<b>Nut M10</b>	<b>Mutter M10</b>	<b>001163</b>
<b>Nut M12</b>	<b>Mutter M12</b>	<b>001165</b>
<b>Washer M5</b>	<b>Unterlegscheibe M5</b>	<b>001176</b>
<b>Washer A6</b>	<b>U-Scheibe A6 M0030 ZN</b>	<b>001179</b>
<b>Washer M8</b>	<b>Unterlegscheibe M8</b>	<b>001181</b>
<b>Washer M10</b>	<b>Unterlegscheibe M10</b>	<b>001186</b>
<b>Washer A10</b>	<b>U-Scheibe A10 DIN 125 ZN</b>	<b>001188</b>
<b>Spring Washer A10</b>	<b>Federring A10 DIN127 ZN</b>	<b>001190</b>
<b>Washer M12</b>	<b>Unterlegscheibe M12</b>	<b>001191</b>
<b>Spring Washer A12</b>	<b>Federring A12 DIN127 ZN</b>	<b>001192</b>
<b>Shaft Washer</b>	<b>Federscheiben</b>	<b>001194</b>
<b>Square Nut M8</b>	<b>Vierkantmutter M8</b>	<b>001205</b>
<b>Woodruff Key</b>	<b>Passfeder</b>	<b>001207</b>
<b>O-Ring</b>	<b>O-Ring</b>	<b>001271</b>
<b>O-Ring</b>	<b>O-Ring</b>	<b>001272</b>



DESCRIPTION	BENENNUNG	Order No. Bestell-Nr.
<b>Back-up Ring Filter Housing</b>	<b>Stützring für Filtergehäuse</b>	<b>001285</b>
<b>O-Ring Filter Housing</b>	<b>O-Ring für Filtergehäuse</b>	<b>001287</b>
<b>O-Ring</b>	<b>O-Ring</b>	<b>001294</b>
<b>Copper Gasket</b>	<b>Kupferdichtung</b>	<b>001323</b>
<b>Circlip A39</b>	<b>Sicherungsring A39 DIN471</b>	<b>001345</b>
<b>Circlip I22</b>	<b>Sicherungsring I22 DIN472</b>	<b>001356</b>
<b>Guide Cylinder 3rd Stage</b>	<b>Führungszylinder 3. Stufe <math>\varnothing</math> 42 mm</b>	<b>001426</b>
<b>Lock Ring</b>	<b>Befestigungsring</b>	<b>001431</b>
<b>V-Belt</b>	<b>Keilriemen LW 450 D, SPA2532</b>	<b>001450</b>
<b>Oil Pressure Switch 0.5-5bar</b>	<b>Druckschalter 0,5-5bar, Öldruckschalter</b>	<b>001525</b>
<b>Oil Drain Hose Clamp</b>	<b>Klemmhalter für Ölablassschlauch, LW720 EG VD8</b>	<b>001527</b>
<b>Oil Drain Valve</b>	<b>Ölablassventil, Kugelhahn</b>	<b>001548</b>
<b>Endpressure Safety Valve CE</b>	<b>Enddrucksicherheitsventil - bauteilgeprüft CE Einstelldruck 225bar</b>	<b>001814</b>
<b>Endpressure Safety Valve CE</b>	<b>Enddrucksicherheitsventil - bauteilgeprüft CE Einstelldruck 250bar</b>	<b>001815</b>
<b>Endpressure Safety Valve CE</b>	<b>Enddrucksicherheitsventil - bauteilgeprüft CE Einstelldruck 330bar</b>	<b>001816</b>
<b>Endpressure Safety Valve CE</b>	<b>Enddrucksicherheitsventil - bauteilgeprüft</b>	<b>001817</b>



DESCRIPTION	BENENNUNG	Order No. Bestell-Nr.
	<b>CE Einstelldruck 350bar</b>	
<b>Washer A10.5</b>	<b>U-Scheibe A10,5 DIN6340 ZN</b>	<b>001828</b>
<b>Bracket Filter Tower 450 E</b>	<b>Halteblech Filtergehäuse LW 450 E</b>	<b>002015</b>
<b>Counter for working hours</b>	<b>Betriebsstundenzähler 10-80 V mit Halteklammer</b>	<b>002090</b>
<b>Spacer Bolt</b>	<b>Distanzschraube (Zylinderkopf 1. Stufe)</b>	<b>002106</b>
<b>Cylinder 1st Stage</b>	<b>Zylinder 1. Stufe <math>\varnothing</math> 95 mm</b>	<b>002111</b>
<b>T-shaped Filter Cartridge Tool</b>	<b>Filterschlüssel 1,7 &amp; 2,3 Liter Behälter</b>	<b>002140</b>
<b>U-Clamp Filter Housing</b>	<b>Haltebügel Filtergehäuse</b>	<b>002147</b>
<b>Drain Hose for Oil</b>	<b>Ölablassschlauch</b>	<b>002153</b>
<b>O-Ring</b>	<b>O-Ring Ölpumpenflansch, 32,2x3 NBR70</b>	<b>002340</b>
<b>Quick Release Coupling Straight G1/8" / 8 for condensate hose</b>	<b>Schnellkupplung gerade G1/4"-8mm für Kondensatschlauch</b>	<b>002356</b>
<b>Quick Release Coupling G1/8" / 6 mm</b>	<b>Schnellkupplung G1/8" / 6mm Schlauch</b>	<b>002358</b>
<b>Quick Release Coupling, straight G1/8" / 8 mm</b>	<b>Schnellkupplung gerade G1/8"-8mm Schlauch, 45.018-8</b>	<b>002361</b>
<b>Filter Assembly, c/w integrated oil-/water separator, Pmax: 350 bar, volume: 1.7 ltr</b>	<b>Hochdruckfiltergehäuse 1,7 Ltr. mit Wasserabscheider Pmax: 350 bar</b>	<b>002366</b>
<b>Valve Head 3rd Stage</b>	<b>Ventilkopf 3. Stufe</b>	<b>002367</b>
<b>Drain Hose for Condensate</b>	<b>Kondensatablassschlauch</b>	<b>002371</b>



DESCRIPTION	BENENNUNG	Order No. Bestell-Nr.
<b>Cone Plug</b>	<b>Verschlusskegel 06mm, Dichtkegel VK6</b>	<b>002395</b>
<b>Compression Cylinder 3rd Stage</b>	<b>Hochdruckzylinder 3. Stufe <math>\varnothing</math> 18 mm</b>	<b>002478</b>
<b>Safety Switch, Cover Lid</b>	<b>Türschalter Sicherheitsschalter für ES Kompressoren</b>	<b>002550</b>
<b>Water Separator</b>	<b>Wasserabscheider Oberteil</b>	<b>002563</b>
<b>Tube</b>	<b>Rohr <math>\varnothing</math>6x1mm Ölpumpe / Druckschalter, inkl. Muttern &amp; Schneidringe</b>	<b>002620</b>
<b>Needle Bearing</b>	<b>Nadellager <math>\varnothing</math>28x<math>\varnothing</math>22x16mm Oberes Pleuellager LW 720 4.Stufe</b>	<b>002673</b>
<b>Oil Level Indicator, c/w gasket</b>	<b>Ölschauglas LW 1300 / 570 / 450 kompl. mit Dichtung</b>	<b>002701</b>
<b>Crankcase with lead/bronze bearing</b>	<b>Kurbelgehäuse mit Bleibronze - Lagerbuchse</b>	<b>002991</b>
<b>Heat Exchanger 1st Stage</b>	<b>Wärmetauscher von Ausgang 1. Stufe</b>	<b>002994</b>
<b>Heat Exchanger 2nd Stage</b>	<b>Wärmetauscher 2. Stufe</b>	<b>002995</b>
<b>Cooling Tube outlet 3<sup>rd</sup> stage to filter housing</b>	<b>Kühlrohr von Ausgang 3. Stufe zum Mole-Carbon - Filtergehäuse (Frontgitter)</b>	<b>003004</b>
<b>Puracon Moisture Controller 12V or 24V DC Version</b>	<b>Puracon Feuchtwächter, 12 od. 24V DC Version</b>	<b>003030</b>
<b>Cooling Tube</b>	<b>Kühlspirale Frontgitter Diesel</b>	<b>003085</b>
<b>Fan Pulley</b>	<b>Ventilator – Keilriemenscheibe (12,5 x <math>\varnothing</math> 620 mm)</b>	<b>003172</b>



DESCRIPTION	BENENNUNG	Order No. Bestell-Nr.
<b>Holding Screw</b>	<b>Halteschrauben Ölschleuderring</b>	<b>003181</b>
<b>Tube Oil Pump outlet</b>	<b>Rohrleitung Ölpumpe Auslass</b>	<b>003184</b>
	<b>Verschraubung Öleinfüllstutzen Kompressorenöl</b>	<b>003185</b>
<b>Oil Filler Compressor Oil</b>	<b>Verschlussstopfen Öleinfüllstutzen Kompressorenöl</b>	<b>003186</b>
<b>Bracket</b>	<b>Halter Öleinfüllstutzen Kompressorenöl</b>	<b>003187</b>
<b>Oil Filler</b>	<b>Öleinfüllstutzen Kompressorenöl</b>	<b>003188</b>
<b>Hose Clamp</b>	<b>Schelle</b>	<b>003189</b>
<b>Crankcase Vent Hose</b>	<b>Entlüftungsschlauch</b>	<b>003190</b>
<b>Plug Screw</b>	<b>Verschlusschraube</b>	<b>003191</b>
<b>Worm Screw</b>	<b>Gewindestift</b>	<b>003193</b>
<b>Worm Screw</b>	<b>Gewindestift</b>	<b>003198</b>
<b>Bracket</b>	<b>Halter, Öldruckschalter</b>	<b>003305</b>
<b>Woodruff Key</b>	<b>Passfeder</b>	<b>0003626</b>
<b>Battery</b>	<b>Batterie LW 450 / 570 D, 12V 45Ah 190A</b>	<b>004571</b>
<b>Control Cable</b>	<b>Steuerleitung Kondensatventil LW 450 Rohrleitung Inkl. Muttern &amp; Schneidringen</b>	<b>004606</b>
<b>Pipe</b>	<b>Rohrleitung SV / DHRV LW 450 D inkl. Muttern &amp; Schneidringen</b>	<b>004607</b>
<b>Tube</b>	<b>Rohrleitung Puracon / Filter, LW 540 D</b>	<b>004608</b>



DESCRIPTION	BENENNUNG	Order No. Bestell-Nr.
	<b>Inkl. Muttern &amp; Schneidringen</b>	
<b>Tube</b>	<b>Rohrleitung Kondensat LW 450 D inkl. Muttern &amp; Schneidringen</b>	<b>004609</b>
<b>Pipe</b>	<b>Rohrleitung Kondensat LW 450 D, inkl. Muttern &amp; Schneidringen</b>	<b>004611</b>
<b>Cover Lid</b>	<b>Kappdeckel LW 450 D Edelstahl</b>	<b>004612</b>
<b>Switch Box</b>	<b>Elektroschaltkasten LW 450 D Edelstahl</b>	<b>004614</b>
<b>Steering Roller</b>	<b>Lenkrolle mit Feststeller <math>\varnothing</math>125mm, Flanschbefestigung</b>	<b>004615</b>
<b>Fixed Roller</b>	<b>Bockrolle <math>\varnothing</math>125mm, Flanschbefestigung</b>	<b>004616</b>
<b>Compressor Housing (s/s version)</b>	<b>Kompressorgehäuse LW 450 D Edelstahl</b>	<b>004617</b>
<b>Strip Terminal</b>	<b>Klemmleiste LW 450 D Edelstahl</b>	<b>004618</b>
<b>Front Grating</b>	<b>Frontgitter LW 450 D, Edelstahl</b>	<b>004619</b>
<b>Bar</b>	<b>Verstärkungsleiste, Edelstahl</b>	<b>004620</b>
<b>Fixing Stud for Battery</b>	<b>Gewindestange Batterie M8 ZN</b>	<b>004771</b>
<b>Battery Bracket</b>	<b>Halteschiene Batterie LW 450 D, chromatiert</b>	<b>004772</b>
<b>Cover Cap</b>	<b>Abdeckkappe + Batteriepol, rot, LW 450 D/ LW 570 D</b>	<b>004773</b>
<b>Earth Strap</b>	<b>Masseband mit Polklemme LW 450 D, Batterie / Motor</b>	<b>004774</b>
<b>Domed Nut M5</b>	<b>Hutmutter, M5 DIN1587 ZN</b>	<b>004899</b>
<b>Engine Hatz Diesel, Type: 1D81C 10,5kW</b>	<b>Motor Hatz Diesel, Typ: 1D81C 10,5kW</b>	<b>005065</b>



DESCRIPTION	BENENNUNG	Order No. Bestell-Nr.
<b>Washer</b>	<b>U-Scheibe 12,5x34,5mm, Kurbelwelle LW 450</b>	<b>005122</b>
<b>Upper Engine Base Plate</b>	<b>Obere Motorplatte LW 450 D</b>	<b>005123</b>
<b>Lower Engine Base Plate</b>	<b>Untere Motorplatte LW 450 D</b>	<b>005124</b>
<b>Elbow Pipe</b>	<b>Rohrbogen Ölablass LW 450 D, 15mm, inkl. Muttern &amp; Schneidringe</b>	<b>005125</b>
<b>Earth Strap</b>	<b>Masseband LW 450 D TCG, Motor / Rahmen, Länge:325mm</b>	<b>005126</b>
<b>Battery Cable</b>	<b>Batteriekabel, rot, ohne Polklemme, LW 450 D</b>	<b>005127</b>
<b>Protection Box</b>	<b>Schutzkasten Puracon, 182x180x90mm</b>	<b>005128</b>
<b>Mounting Plate</b>	<b>Montageplatte für Schutzkasten 005128, verzinkt, 150x150mm</b>	<b>005129</b>
<b>Bracket plate, alloy</b>	<b>Alu Befestigungsplatte Puracon</b>	<b>005130</b>
<b>Angle Plate</b>	<b>Alu Winkelblech für Puracon-Kabel, LW 450 D TCG</b>	<b>005131</b>
<b>Sheet Bracket for Puracon</b>	<b>PVC Halter für Puracon Halteblech, grau, LW 450 D TCG</b>	<b>005132</b>
<b>Cable Protection Hose</b>	<b>Kabel Schutzschlauch LW 450 D, Seewasserbeständig, TCG</b>	<b>005133</b>
<b>Cable Clamp PG29</b>	<b>PG Verschraubung PG29, kompl. mit Klemmmutter</b>	<b>005134</b>
<b>Hose Clamp</b>	<b>Schlauchschelle LW 450 D, f. Kabel-Schutzschlauch</b>	<b>005135</b>
<b>Ring Bolt</b>	<b>Transportöse LW 450 D TCG, rosa, klappbar</b>	<b>005136</b>



DESCRIPTION	BENENNUNG	Order No. Bestell-Nr.
<b>Cover Lid Brass Bushes</b>	<b>Klappdeckelhülsen Messing (1 Paar) LW 280E, LW 450 D/E, LW 570 D/E</b>	<b>005137</b>

# EG-KONFORMITÄTSERKLÄRUNG



**Lenhardt & Wagner GmbH**  
**An der Tuchbleiche 39**  
**D-68623 Lampertheim - Hüttenfeld**  
**Germany**



Tel.: 0 62 56 – 85 880 0  
 Fax: 0 62 56 – 85 880 14  
 www.lw-compressors.com

<b>EG-KONFORMITÄTSERKLÄRUNG IM SINNE DER EG-MASCHINENRICHTLINIE 2006/42/EG ANHANG II A UND IM SINNE DER EG-DRUCKGERÄTERICHTLINIE 97/23/EG ANHANG VII</b> <b>EC-CONFORMITY DECLARATION IN ACCORDANCE WITH EC-MACHINERY DIRECTIVE 2006/42/EC APPENDIX II A EC PRESSURE EQUIPMENT DIRECTIVE 97/23/EC APPENDIX VII</b>	
Hiermit erklären wir,	Herewith we
<b>Lenhardt &amp; Wagner GmbH</b> <b>An der Tuchbleiche 39</b> <b>D-68623 Lampertheim-Hüttenfeld</b> <b>Germany</b>	
<p>dass die nachfolgend bezeichnete Baueinheit aufgrund ihrer Konzipierung und Bauart sowie in der von uns in Verkehr gebrachten Ausführung, den einschlägigen grundlegenden Sicherheits- und Gesundheitsanforderungen der EG-Richtlinien entspricht. Für die Druckgeräte der Baueinheit liegt eine EG-Baumusterprüfung mit der Prüfnummer 0248/02 vor. Die Qualitätssicherung der Produktion der Baueinheit wurde einem Konformitätsbewertungsverfahren nach <b>Modul C1</b> durch den TÜV Technische Überwachung Hessen GmbH, benannte Stelle, Kennnummer 0091, unterzogen. Die Baueinheit fällt in die <b>Kategorie II</b> nach Diagramm 2 der DGRL 97/23/EG Anhang II.</p> <p>Bei einer nicht mit uns abgestimmten Änderung der Baueinheit verliert diese Erklärung ihre Gültigkeit.</p>	<p>confirm that the below mentioned unit complies with the basic safety and health requirements of the EC directives concerning design, construction and putting the model into circulation. For the pressure vessels of the unit exists an EC type examination certificate with the report no. 0248/02. The production quality assurance of the unit was inspected by TÜV Technische Überwachung Hessen GmbH, notified body, No. 0091. Conformity Assessment Procedure <b>Module C1</b> was applied. For the unit comes within the limits of <b>category II</b> to table 2 of PED 97/23/EC Annex II.</p> <p>This declaration is no longer valid if the unit has been modified without our agreement.</p>
<b>Bezeichnung der Baueinheit:</b> <b>Description of Unit:</b>	<b>Atemluftkompressor</b> <b>Breathing Air Compressor</b>
<b>Typ der Baueinheit:</b> <b>Type of Unit:</b>	<b>LW 450 D</b>
<b>Einschlägige EG-Richtlinien</b>	<b>Relevant EC-Directives</b>

# EG-KONFORMITÄTSERKLÄRUNG



<ul style="list-style-type: none"> <li>• 2006/42/EG - Maschinenrichtlinie</li> <li>• 97/23/EG - Druckgeräterichtlinie</li> <li>• 2003/10/EG - Gefährdung durch physikalische Einwirkungen (Lärm)</li> <li>• 2000/14/EG - RL Umweltlärm von Maschinen</li> </ul>	<ul style="list-style-type: none"> <li>• 2006/42/EC - Machinery Directive</li> <li>• 97/23/EC - Pressure Equipment Directive</li> <li>• 2003/10/EC - Risks arising from physical agents (noise)</li> <li>• 2000/14/EC - Directive relating to the noise emission in the environment by equipment for use outdoors</li> </ul>
<p><b>Angewandte harmonisierte Normen</b> – insbesondere:</p> <p>EN ISO 12100:2010, DIN EN 12021:1998, DIN EN 1012-1:2010, DIN EN ISO 13850:2008, DIN EN ISO 13857:2008, DIN EN 60204-1:2006</p>	<p><b>Applicable and adapted Norms</b> - particularly:</p> <p>EN ISO 12100:2010, DIN EN 12021:1998, DIN EN 1012-1:2010, DIN EN ISO 13850:2008, DIN EN ISO 13857:2008, DIN EN 60204-1:2006</p>
<p><b>Angewandte nationale Normen und technische Spezifikationen - insbesondere:</b></p> <ol style="list-style-type: none"> <li>1) AD 2000 Merkblätter</li> <li>2) Technische Regeln Druckgase (TRG): TRG 400, 401, 402 (ohne Betriebsstätte) und TRG 790</li> </ol>	<p><b>Applicable national Norms and technical Specification – particularly:</b></p> <ol style="list-style-type: none"> <li>1) AD 2000 Bulletins</li> <li>2) Technical Rules for compressed Gas (TRG 400, 401, 402 (without manufacturing facility) and TRG 790)</li> </ol>

Lampertheim - Hüttenfeld, den: 08 Juni 2011

<p><b>LENHARDT &amp; WAGNER GMBH</b></p>  <p>Bernd Wagner Geschäftsführer / Managing Director</p>		
--	---	--